

September 10th 2024

Graphene synthesis project update

1. Biochar synthesis

- Overall seven syntheses finished with hemp fibers from BAFA neu GmbH
 - three syntheses done with 0.02M sulfuric acid
 - first product not representative, not used further
 - second and third batch converted (see below)
 - four syntheses done with 0.10M sulfuric acid
 - very similar observations and outputs
 - products of these have been combined/homogenized
 - part of the combined lots has been converted
- Canadian Rockies Hemp arrived and cleared customs
 - several standard synthesis batches finished, seven of these (11.2 g) combined and homogenized
 - additional experiments done with higher concentrated sulfuric acid (1.5%, 2.0%, 5.0%)
 - one experiment performed under stirring, using cut up hemp fibers, product is finer and more homogeneous
 - one experiment performed with sulfuric acid pre-treatment of hemp (95 °C)
- Larger vessel reactivated, first production batch completed (14.9 g output)
- Repeat experiment finished, 15.4 g output
- Two further large-scale batches in progress, approx. 30 g total product expected

2. Biochar analysis

- Sample of combined biochar (milled, MB2946X_gem) analyzed by SEM and Raman for reference

3. Graphene synthesis

- two experiments finished with steep heating ramp (20-30 °C/min)
 - biochar ground manually for first experiment (TB1131)
 - laboratory mill used for second experiment (TB1132)
 - products not yet characterized
 - no serious handling issues
- two experiments performed with much gentler heating ramp (3 °C/min, TB1133/1134)
 - better handling but no other apparent difference

-
- one experiment performed at 5 °C/min (MB2946)
 - 2 g of combined biochar milled with 2 g of KOH and used for several batches on 0.25 g scale
 - 800 °C, 1 h: minimal yield (MB2947A)
 - 800 °C, 2 h: minimal yield (MB2947B)
 - 800 °C, 3 h: no output (MB2947C)
 - ➔ Inertion apparently insufficient and material likely incinerated
 - 800 °C, 3 h repeat, much higher Ar stream: 38 mg output obtained (MB2947D)
 - 800 °C, 1 h, nitrogen inertion: 60 mg output (TB1135-1)
 - 800 °C, 1 h, increased nitrogen inertion: 70 mg output (TB1135-2)
 - 2 g of combined biochar milled with 2 g of KOH and used for several batches on 0.25 g scale
 - 800 °C, 2 h, inertion equivalent to TB1135-2: 70 mg output (MB2952B)
 - 800 °C, 3 h, inertion equivalent to TB1135-2: 50 mg output (MB2952C)
 - ➔ smoldering observed upon contact of the cold material with air (see video)
 - 800 °C, 3 h, inertion equivalent to TB1135-2: 60 mg output (MB2952C2)
 - ➔ material wetted with water before/during removal from the apparatus
 - Oxygen sensor shows complete inertion of apparatus within 3 minutes at selected nitrogen stream (equivalent to TB1135-2)
 - 2 g of combined biochar milled with 3 g of KOH and used for several batches on 0.25 g scale
 - 800 °C, 1 h, standard inertion: Quartz tube shattered, only 7 mg output (MB2955A)
 - 800 °C, 1 h, standard inertion (repeat of MB2955A): 90 mg output (MB2955A2)
 - 800 °C, 2 h, standard inertion: 80 mg output (TB1136)
 - 2 g of combined biochar milled with 4 g of KOH and used for several batches on 0.25 g scale
 - 800 °C, 1 h, standard inertion: 80 mg output (MB2962A)
 - 800 °C, 2 h, standard inertion: 90 mg output (MB2962B)
 - 0.6 g of biochar (cut up, hydrolyzed under stirring) milled with 0.6 g of KOH and used for two batches on 0.2 – 0.3 g scale
 - 800 °C, 1 h, standard inertion: 70 mg output (MB2963A)
 - 800 °C, 2 h, standard inertion: 120 mg output (MB2963B)
 - 2 g of combined biochar milled with 8 g of KOH and used for several batches on 0.25 g scale
 - 800 °C, 1 h, standard inertion: 60 mg output (TB1137-1)
 - 800 °C, 2 h, standard inertion: 60 mg output (TB1137-2)
 - 800 °C, 1 h, standard inertion: 70 mg output (TB1137-3)
 - 2 g of biochar lot MB2959 milled with 12 g of KOH and used for several batches
 - 800 °C, 1 h, standard inertion: 24 mg output (MB2965A)
 - 800 °C, 2 h, standard inertion: 13 mg output (MB2965B)
 - 800 °C, 2 h, standard inertion (oven B): 7 mg output (MB2965B2)

- 2 g of biochar lot MB2959 milled with 8 g of KOH and used for several batches
 - 800 °C, 1 h, standard inertion (oven B): 52 mg output (MB2966A)
 - 800 °C, 2 h, standard inertion: 46 mg output (MB2966B)
- 1.2 g of biochar lot MB2964 milled with 4.8 g of KOH and used for several batches
 - 800 °C, 1 h, standard inertion (oven B): 57 mg output (MB2967A)
 - 800 °C, 2 h, standard inertion: 42 mg output (MB2967B)
- 1.4 g of biochar lot MB2957 (from 1.5% H₂SO₄) milled with 2.1 g of KOH and used for several batches
 - 800 °C, 1 h, standard inertion (oven B): 63 mg output (MB2970A)
 - 800 °C, 2 h, standard inertion: 19 mg output (MB2970B)
- 1.4 g of biochar lot MB2958 (from 2% H₂SO₄) milled with 2.1 g of KOH and used for several batches
 - 800 °C, 1 h, standard inertion (oven B): 54 mg output (MB2971A)
 - 800 °C, 2 h, standard inertion: 66 mg output (MB2971B)
- 1.4 g of biochar lot MB2961 (from 5% H₂SO₄) milled with 2.1 g of KOH and used for several batches
 - 800 °C, 1 h, standard inertion (oven B): 88 mg output (MB2972A)
 - 800 °C, 2 h, standard inertion: 57 mg output (MB2972B)
- 1.4 g of biochar lot MB2959 milled with 2.1 g of KOH and used for two identical batches (reproducibility experiment)
 - 800 °C, 1 h, standard inertion (oven B): 42 mg output (MB2973A)
 - 800 °C, 1 h, standard inertion: 90 mg output (MB2973B)
- 1.5 g of biochar lot MB2959 milled with 2.3 g of KOH and used for two batches (milling time experiment)
 - milling time 5 min, 800 °C, 1 h, standard inertion (oven B): 78 mg output (MB2974A)
 - milling time 1 min, 800 °C, 1 h, standard inertion: 81 mg output (MB2974B)
- 1.5 g of biochar lot MB2959 milled with 2.3 g of KOH and used for two batches (milling time experiment)
 - milling time 5 min, 800 °C, 2 h, standard inertion (oven B): 59 mg output (MB2975A)
 - milling time 1 min, 800 °C, 2 h, standard inertion: 80 mg output (MB2975B)
- 2.0 g of biochar lot MB2959 milled with 3.0 g of KOH and used for two batches (pellet pressing experiment)
 - 0.6 g pellet, 800 °C, 1 h, standard inertion (oven B): 83 mg output (MB2976A)
 - 0.6 g pellet, 800 °C, 2 h, standard inertion: 108 mg output (MB2976B)

-
- Biochar/KOH mixture from MB2976 used for new reproducibility experiment (analogous to MB2973)
 - 800 °C, 1 h, standard inertion (oven B): 83 mg output (MB2979A)
 - 800 °C, 1 h, standard inertion: 104 mg output (MB2979B)

 - 2.5 g of biochar lots MB2959/2956 milled with 3.8 g of KOH for 10/20 min and used for four batches (pellet pressing experiment)
 - 0.6 g pellet, 20 min milling time, 800 °C, 1 h, standard inertion (oven B): 78 mg output (MB2980A)
 - 0.6 g pellet, 10 min milling time, 800 °C, 1 h, standard inertion (oven A): 95 mg output (MB2980B)
 - 1.3 g pellet, 20 min milling time, 800 °C, 1 h, standard inertion (oven B): 163 mg output (MB2980C)
 - 1.3 g pellet, 10 min milling time, 800 °C, 1 h, standard inertion (oven A): 232 mg output (MB2980D)

 - 2.5 g of biochar lot MB2978 milled with 3.8 g of KOH for 10/20 min and used for ten batches
 - 800 °C, 1 h, 10 min milling time, standard inertion (oven A): 95 mg (KJo-0165A)
 - 800 °C, 1 h, 20 min milling time, inertion potentially nonstandard (oven B): 146 mg (KJo-0165B)
 - 800 °C, 1 h, 10 min milling time, 10 °C/min, standard inertion (oven A): 125 mg (KJo-0166A)
 - 800 °C, 1 h, 20 min milling time, 10 °C/min, standard inertion (oven B): 114 mg (KJo-0166B)
 - 800 °C, 4 h, 10 min milling time, 3 °C/min, 0.6 g pellet pressed, standard inertion (oven A): 102 mg (KJo-0167A)
 - 800 °C, 4 h, 20 min milling time, 3 °C/min, 0.6 g pellet pressed, standard inertion (oven B): 61 mg (KJo-0167B)
 - 900 °C, 2 h, 10 min milling time, 3 °C/min, 0.6 g pellet pressed, standard inertion (oven A): 23 mg (KJo-0168A)
 - 900 °C, 1 h, 20 min milling time, 3 °C/min, 0.6 g pellet pressed, standard inertion (oven B): 89 mg (KJo-0168B)
 - 800 °C, 1 h, 10 min milling time, 3 °C/min, 2.0 g pellet pressed, standard inertion (oven B): 232 mg (KJo-0169)
 - 800 °C, 1 h, 20 min milling time, 3 °C/min, 2.7 g pellet pressed, standard inertion (oven B): 619 mg (KJo-0170)

 - 5 g of biochar lot MB2978 milled with 7.5 g of KOH for 5 min and used for two batches
 - 800 °C, 1 h, 3 °C/min, 2 x 2.0 g pellets pressed, standard inertion (oven B): 642 mg (KJo-0171A)
 - 800 °C, 1 h, 3 °C/min, 0.6 g pellet pressed, standard inertion (oven A): 128 mg (KJo-0171B)

- 2.5 g of biochar lot MB2978 milled with 2.5 g of KOH for 2.5 min and used for two batches
 - 800 °C, 1 h, 3 °C/min, 0.6 g pellet pressed, standard inertion (oven B): 243 mg (KJo-0172A)
 - 800 °C, 2 h, 3 °C/min, 0.6 g pellet pressed, standard inertion (oven A): 169 mg (KJo-0172B)

- 3.0 g of biochar lot MB2978 milled with 4.5 g of KOH for 5 min and used for three batches
 - 800 °C, 1 h, 3 °C/min, 2 x 2.0 g pellets pressed, standard inertion (oven A), quartz tube shattered: output tbd (KJo-0175)
 - 800 °C, 1 h, 1.5 °C/min, 0.6 g pellet pressed, standard inertion (oven B): output tbd (KJo-0176)
 - 800 °C, 1 h, 3 °C/min, 2 x 2.0 g pellets pressed, standard inertion (oven A): output tbd (KJo-0175)

- Total quantity of material with sufficient quality (judging by SEM data) available: 1.6 g
 - MB2976 A/B: approx. 100 mg
 - MB2980 A: approx. 50 mg
 - MB2980 C/D: approx. 300 mg
 - KJo-0166 B: approx. 100 mg
 - KJo-0167 B: approx. 50 mg
 - KJo-0168 B: approx. 70 mg
 - KJo-0171 A: approx. 600 mg
 - KJo-0171 B: approx. 100 mg
 - KJo-0172 A: approx. 220 mg

4. Graphene analysis

- SEM (and partially Raman) results available for
 - TB1133, MB2946A, MB2947D, TB1135-1, TB1135-2, MB2952B, MB2952C, MB2952C2, MB2955A, MB2955A2, TB1136, MB2962A/B, MB2963A/B, TB1137-1/2/3 (step 2 products), MB2965B, MB2965B2, MB2966A/B, MB2967A/B, MB2970A/B, MB2971A/B, MB2972A/B, MB2973A/B, MB2974A/B, MB2975A/B, MB2976A/B, MB2979A/B, MB2980A/B/C/D, KJo-0165A/B, KJo-0166A/B, KJo-0167A/B, KJo-0168A/B, KJo-0169, KJo-0170, KJo-0171A/B, KJo-0172A/B, (step 2 products)
 - 900561-500MG (Sigma-Aldrich reference)
 - 924458-500MG (Sigma-Aldrich reference “Single-layer graphene sheets for battery, Bio-sourced”)
- TEM results available for
 - MB2955A2 (step 2 product)

5. Currently open questions

Experiment overview – Step 1

Experiment	Reactor	Raw material			Acid			T	t	pressure		Wash		Output		
MB2928	AV1	6.0 g	BAFA neu Hemp Fibre VF	100.0 g	0.19%	0.02 M	Sulfuric acid	180 °C	22.5 h	8.7 bar	-> 10.4 bar	742 g	Water	2.6 g		
Comment	Fibres not completely covered by liquid															
MB2933	AV1	6.1 g	BAFA neu Hemp Fibre VF	174.0 g	0.19%	0.02 M	Sulfuric acid	180 °C	24 h	8.7 bar	-> 9.5 bar	647 g	Water	1.2 g		
Comment	dark crusts on glassware, metal and liquid surface removed before filtration															
MB2935	AV1	6.0 g	BAFA neu Hemp Fibre VF	172.9 g	0.19%	0.02 M	Sulfuric acid	180 °C	23 h	8.8 bar	-> 9.5 bar	500 g	Water	1.3 g		
Comment	dark crusts on glassware, metal and liquid surface removed before filtration															
MB2936	AV1	6.0 g	BAFA neu Hemp Fibre VF	172.4 g	0.96%	0.10 M	Sulfuric acid	180 °C	23 h	8.8 bar	-> 10.6 bar	589 g	Water	0.8 g	Combined and homogenized as lot no MRa231	
Comment	dark crusts on glassware, metal and liquid surface removed before filtration															
MRa225	AV1	6.0 g	BAFA neu Hemp Fibre VF	153.8 g	0.96%	0.10 M	Sulfuric acid	180 °C	24 h	?	-> 10.5 bar	500 g	Water	0.9 g		
Comment	dark crusts on glassware, metal and liquid surface removed before filtration															
MRa228	AV1	6.3 g	BAFA neu Hemp Fibre VF	154.0 g	0.96%	0.10 M	Sulfuric acid	180 °C	22.5 h	8.7 bar	-> 11.0 bar	500 g	Water	0.9 g		
Comment	dark crusts on glassware, metal and liquid surface removed before filtration															
MRa231	AV1	6.1 g	BAFA neu Hemp Fibre VF	168.8 g	0.96%	0.10 M	Sulfuric acid	180 °C	23.5 h	8.0 bar	-> 10.5 bar	500 g	Water	0.8 g		
Comment	dark crusts on glassware, metal and liquid surface removed before filtration															
MB2937	AV1	9.4 g	Canadian Rockies Hemp	179.3 g	0.96%	0.10 M	Sulfuric acid	180 °C	24 h	8.6 bar	-> 10.9 bar	569 g	Water	1.6 g	Combined and homogenized as lot no MB2946X	
Comment	very low amount of foreign material observed and removed during filtration															
MB2938	AV1	8.9 g	Canadian Rockies Hemp	175.0 g	0.96%	0.10 M	Sulfuric acid	180 °C	23.5 h	9.2 bar	-> 13.2 bar	577 g	Water	1.4 g		
Comment	very low amount of foreign material observed and removed during filtration															
MB2940	AV1	9.2 g	Canadian Rockies Hemp	177.1 g	0.96%	0.10 M	Sulfuric acid	180 °C	22.5 h	8.7 bar	-> 10.6 bar	555 g	Water	1.5 g		
Comment	very low amount of foreign material observed and removed during filtration															
MB2942	AV1	8.9 g	Canadian Rockies Hemp	177.6 g	0.96%	0.10 M	Sulfuric acid	180 °C	23 h	8.3 bar	-> 13.5 bar	578 g	Water	1.6 g		
Comment	low amount of foreign material observed and removed during filtration															
MB2943	AV1	9.8 g	Canadian Rockies Hemp	178.2 g	0.96%	0.10 M	Sulfuric acid	180 °C	24 h	8.3 bar	-> 12.7 bar	611 g	Water	1.7 g		
Comment	low amount of foreign material observed and removed during filtration															
MB2944	AV1	9.0 g	Canadian Rockies Hemp	178.4 g	0.96%	0.10 M	Sulfuric acid	180 °C	24 h	8.4 bar	-> 9.7 bar	593 g	Water	1.8 g		
Comment	low amount of foreign material observed and removed during filtration															
MB2945	AV1	9.1 g	Canadian Rockies Hemp	177.7 g	0.96%	0.10 M	Sulfuric acid	180 °C	24 h	8.7 bar	-> 9.8 bar	6 g	Water	1.6 g		
Comment	low amount of foreign material observed and removed during filtration															
MB2948	AV1	9.4 g	Canadian Rockies Hemp	175.1 g	0.96%	0.10 M	Sulfuric acid	180 °C	25 h	9.0 bar	-> 12.6 bar	475 g	Water	1.7 g		
Comment	low amount of foreign material observed and removed during filtration															

Experiment	Reactor	Raw material	Acid	T	t	pressure	Wash	Output
MB2949	AV1	9.2 g Canadian Rockies Hemp	174.3 g 0.96% 0.10 M Sulfuric acid	180 °C	23.5 h	8.4 bar -> 10.2 bar	538 g Water	1.8 g
Comment	low amount of foreign material observed and removed during filtration							
MB2950	AV1	9.1 g Canadian Rockies Hemp	170.5 g 0.96% 0.10 M Sulfuric acid	180 °C	23 h	-> 11.1 bar	534 g Water	1.6 g
Comment	low amount of foreign material observed and removed during filtration							
MB2951	AV1	9.3 g Canadian Rockies Hemp	178.5 g 0.96% 0.10 M Sulfuric acid	180 °C	24 h	9.1 bar -> 11.2 bar	575 g Water	1.8 g
Comment	low amount of foreign material observed and removed during filtration							
MRa255	AV1	9.2 g Canadian Rockies Hemp	170.8 g 0.96% 0.10 M Sulfuric acid	180 °C	23.5 h	8.1 bar -> 12.8 bar	488 g Water	1.7 g
Comment	some foreign material observed and removed during filtration							
MB2953	AV1	9.7 g Canadian Rockies Hemp	177.1 g 0.96% 0.10 M Sulfuric acid	180 °C	23.5 h	9.1 bar -> 10.4 bar	558 g Water	1.8 g
Comment	low amount of foreign material observed and removed during filtration							
MB2956	AV1	9.8 g Canadian Rockies Hemp	172.0 g 0.96% 0.10 M Sulfuric acid	180 °C	24 h	8.6 bar -> 12.5 bar	548 g Water	1.9 g
Comment	low amount of foreign material observed and removed during filtration							
MB2957	AV1	9.1 g Canadian Rockies Hemp	176.8 g 1.50% 0.15 M Sulfuric acid	180 °C	23.5 h	8.8 bar -> 8.5 bar	589 g Water	1.5 g
Comment								
MB2958	AV1	9.3 g Canadian Rockies Hemp	177.0 g 2.00% 0.20 M Sulfuric acid	180 °C	24 h	8.9 bar -> 8.7 bar	562 g Water	1.8 g
Comment								
MB2959	AV5	76.0 g Canadian Rockies Hemp	953.0 g 1.00% 0.10 M Sulfuric acid	180 °C	25 h		3957 g Water	14.9 g
Comment	low amount of foreign material observed and removed during filtration							
MB2960	AV1	3.8 g Canadian Rockies Hemp (cut)	151.0 g 1.00% 0.10 M Sulfuric acid	180 °C	24 h	8.8 bar -> 10.5 bar	300 g Water	0.6 g
Comment	Reaction performed with stirring							
MB2961	AV1	9.9 g Canadian Rockies Hemp	172.0 g 5.00% 0.51 M Sulfuric acid	180 °C	24 h	10.1 bar -> 16.1 bar	563 g Water	1.7 g
Comment	low amount of foreign material observed and removed during filtration							
MB2964	AV1	9.0 g Canadian Rockies Hemp	211.0 g + 140.8 g 1.00% 0.10 M Sulfuric acid	180 °C	24 h	8.6 bar -> 8.8 bar	310 g + 603 g Water	1.3 g
Comment	Hemp boiled with 1% H2SO4 at 95 °C, filtered and washed, then heated in Autoclave with fresh acid							
MB2978	AV5	76.3 g Canadian Rockies Hemp	822.0 g 1.00% 0.10 M Sulfuric acid	180 °C	22 h		4112 g Water	15.4 g
Comment								
KJo-0173	AV5	77.1 g Canadian Rockies Hemp	942.1 g 1.00% 0.10 M Sulfuric acid	180 °C	24 h		4283 g Water	
Comment								

Experiment overview – Step 2

Experiment	Oven	Qty	Lot	Base	grinding	Gas	T (rate)	T (max)	t	Wash	Drying	Output
TB1131	A	1.2 g	MB2933	1.2 g KOH (90%)	manual	Ar	20-27 °C/min	790 °C	1 h	20 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.16 g
Comment		ground biochar: brown powder, strong electrostatic charge										
TB1132	A	1.3 g	MB2935	1.3 g KOH (90%)	mill (2 min)	Ar	20-29 °C/min	792 °C	1 h	20 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.3 g
Comment		ground biochar: brown powder										
TB1133	A	1.0 g	MRa231	1.0 g KOH (90%)	mill (1 min)	Ar	3 °C/min	785 °C	1 h	20 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.3 g
Comment		ground biochar: brown powder; see temperature trend										
TB1134	A	1.0 g	MRa231	1.0 g KOH (90%)	mill (2 min)	Ar	3 °C/min	771 °C	1 h	20 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.3 g
Comment		ground biochar: brown powder; see temperature trend										
MB2946	A	1.0 g	MB2946X	1.0 g KOH (90%)	mill (1 min)	Ar	5 °C/min	770 °C	1 h	22 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.3 g
Comment		ground biochar: brown powder; see temperature trend										
MB2947A	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	Ar	3 °C/min	803 °C	1 h	10 g 10% HCl (+ water)	40 °C N2 stream 210 mbar	< 0.01 g
Comment		ground biochar: brown powder; see temperature trend										
MB2947B	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	Ar	3 °C/min	804 °C	2 h	10 g 10% HCl (+ water)	40 °C N2 stream 210 mbar	< 0.01 g
Comment		ground biochar: brown powder; see temperature trend										
MB2947C	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	Ar	3 °C/min	806 °C	3 h	Batch discarded		
Comment		ground biochar: brown powder; see temperature trend										
MB2947D	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	Ar	3 °C/min	810 °C	3 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	38 mg
Comment		ground biochar: brown powder; see temperature trend										
TB1135-1	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	14 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.06 g
Comment		ground biochar: brown powder; see temperature trend										
TB1135-2	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	14 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.07 g
Comment		ground biochar: brown powder; see temperature trend										
MB2952B	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.07 g
Comment		ground biochar: brown powder; see temperature trend										
MB2952C	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	3 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.05 g
Comment		ground biochar: brown powder; see temperature trend										

Experiment	Oven	Qty	Lot	Base	grinding	Gas	T (rate)	T (max)	t	Wash	Drying	Output
MB2952C2	A	0.25 g	MB2946X	0.25 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.06 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2955A	A	0.25 g	MB2946X	0.38 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	7 mg
Comment		Quartz tube shattered during experiment								(+ water)	(atm. Pressure)	
MB2955A2	A	0.25 g	MB2946X	0.38 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.09 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
TB1136	A	0.26 g	MB2946X	0.39 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	2 h	14 g 10% HCl	100 °C N2 stream	0.08 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2962A	A	0.25 g	MB2946X	0.50 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.08 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2962B	A	0.25 g	MB2946X	0.50 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.09 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2963A	A	0.22 g	MB2960	0.22 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.07 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2963B	A	0.29 g	MB2960	0.29 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.12 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
TB1137-1	A	0.26 g	MB2946X	1.06 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	23 g 10% HCl	100 °C N2 stream	0.06 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
TB1137-2	A	0.28 g	MB2946X	1.13 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	2 h	23 g 10% HCl	100 °C N2 stream	0.06 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
TB1137-3	A	0.26 g	MB2946X	1.06 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	23 g 10% HCl	100 °C N2 stream	0.07 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2965A	A	0.22 g	MB2959	1.08 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	20 g 10% HCl	100 °C N2 stream	0.02 g
Comment		ground biochar/KOH mixture likely absorbed some moisture; see temperature trend								(+ water)	(atm. Pressure)	
MB2965B	A	0.22 g	MB2959	1.08 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	20 g 10% HCl	100 °C N2 stream	0.01 g
Comment		ground biochar/KOH mixture likely absorbed some moisture; see temperature trend								(+ water)	(atm. Pressure)	
MB2965B2	B	0.22 g	MB2959	1.08 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	20 g 10% HCl	100 °C N2 stream	0.01 g
Comment		ground biochar/KOH mixture likely absorbed some moisture; see temperature trend								(+ water)	(atm. Pressure)	

Experiment	Oven	Qty	Lot	Base	grinding	Gas	T (rate)	T (max)	t	Wash	Drying	Output
MB2966A	B	0.26 g	MB2959	1.04 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	20 g 10% HCl	100 °C N2 stream	0.05 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2966B	A	0.26 g	MB2959	1.04 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	20 g 10% HCl	100 °C N2 stream	0.05 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2967A	B	0.26 g	MB2964	1.04 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	20 g 10% HCl	100 °C N2 stream	0.06 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2967B	A	0.26 g	MB2964	1.04 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	20 g 10% HCl	100 °C N2 stream	0.04 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2970A	B	0.24 g	MB2957	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.06 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2970B	A	0.24 g	MB2957	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.02 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2971A	B	0.24 g	MB2958	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.05 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2971B	A	0.24 g	MB2958	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.07 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2972A	B	0.24 g	MB2961	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.09 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2972B	A	0.24 g	MB2961	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.06 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2973A	B	0.24 g	MB2959	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.04 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2973B	A	0.24 g	MB2959	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.09 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2974A	B	0.24 g	MB2959	0.36 g KOH (90%)	mill (5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.08 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2974B	A	0.24 g	MB2959	0.36 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.08 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	

Experiment	Oven	Qty	Lot	Base	grinding	Gas	T (rate)	T (max)	t	Wash	Drying	Output
MB2975A	B	0.24 g	MB2959	0.36 g KOH (90%)	mill (5 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.06 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2975B	A	0.24 g	MB2959	0.36 g KOH (90%)	mill (1 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.08 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2976A	B	0.24 g	MB2959	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.08 g
Comment		ground biochar (brown powder) compacted to pellet; see temperature trend								(+ water)	(atm. Pressure)	
MB2976B	A	0.24 g	MB2959	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl	100 °C N2 stream	0.11 g
Comment		ground biochar (brown powder) compacted to pellet; see temperature trend								(+ water)	(atm. Pressure)	
MB2979A	B	0.24 g	MB2959	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.08 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2979B	A	0.24 g	MB2959	0.36 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.10 g
Comment		ground biochar: brown powder; see temperature trend								(+ water)	(atm. Pressure)	
MB2980A	B	0.24 g	MB2959/2956	0.36 g KOH (90%)	mill (20 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.08 g
		ground biochar (brown powder) compacted to pellet								(+ water)	(atm. Pressure)	
MB2980B	A	0.24 g	MB2959/2956	0.36 g KOH (90%)	mill (10 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.10 g
		ground biochar (brown powder) compacted to pellet								(+ water)	(atm. Pressure)	
MB2980C	B	0.52 g	MB2959/2956	0.78 g KOH (90%)	mill (20 min)	N2	3 °C/min	800 °C	1 h	21 g 10% HCl	100 °C N2 stream	0.16 g
		ground biochar (brown powder) compacted to pellet								(+ water)	(atm. Pressure)	
MB2980D	A	0.52 g	MB2959/2956	0.78 g KOH (90%)	mill (10 min)	N2	3 °C/min	800 °C	1 h	21 g 10% HCl	100 °C N2 stream	0.23 g
		ground biochar (brown powder) compacted to pellet								(+ water)	(atm. Pressure)	
KJo-0165A	A	0.24 g	MB2978	0.36 g KOH (90%)	mill (10 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl	100 °C N2 stream	0.09 g
		ground biochar: brown powder								(+ water)	(atm. Pressure)	
KJo-0165B	B	0.24 g	MB2978	0.36 g KOH (90%)	mill (20 min)	N2	3 °C/min	800 °C	1 h	11 g 10% HCl	100 °C N2 stream	0.15 g
		ground biochar: brown powder								(+ water)	(atm. Pressure)	
KJo-0166A	A	0.24 g	MB2978	0.36 g KOH (90%)	mill (10 min)	N2	10 °C/min	800 °C	1 h	11 g 10% HCl	100 °C N2 stream	0.13 g
		ground biochar: brown powder								(+ water)	(atm. Pressure)	
KJo-0166B	B	0.24 g	MB2978	0.36 g KOH (90%)	mill (20 min)	N2	10 °C/min	800 °C	1 h	11 g 10% HCl	100 °C N2 stream	0.11 g
		ground biochar: brown powder								(+ water)	(atm. Pressure)	

Experiment	Oven	Qty	Lot	Base	grinding	Gas	T (rate)	T (max)	t	Wash	Drying	Output
KJo-0167A	A	0.24 g	MB2978	0.36 g KOH (90%)	mill (10 min)	N2	3 °C/min	800 °C	4 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.10 g
		ground biochar (brown powder) compacted to pellet										
KJo-0167B	B	0.24 g	MB2978	0.36 g KOH (90%)	mill (20 min)	N2	3 °C/min	800 °C	4 h	11 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.06 g
		ground biochar (brown powder) compacted to pellet										
KJo-0168A	A	0.24 g	MB2978	0.36 g KOH (90%)	mill (10 min)	N2	3 °C/min	900 °C	2 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.02 g
		ground biochar (brown powder) compacted to pellet										
KJo-0168B	B	0.24 g	MB2978	0.36 g KOH (90%)	mill (20 min)	N2	3 °C/min	900 °C	1 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.09 g
		ground biochar (brown powder) compacted to pellet										
KJo-0169	B	0.80 g	MB2978	1.20 g KOH (90%)	mill (10 min)	N2	3 °C/min	800 °C	1 h	30 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.23 g
		ground biochar (brown powder) compacted to pellet										
KJo-0170	B	1.07 g	MB2978	1.61 g KOH (90%)	mill (20 min)	N2	3 °C/min	800 °C	1 h	38 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.62 g
		ground biochar (brown powder) compacted to pellet										
KJo-0171A	B	1.60 g	MB2978	2.40 g KOH (90%)	mill (5 min)	N2	3 °C/min	800 °C	1 h	60 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.64 g
		ground biochar (brown powder) compacted to two pellets of equal size										
KJo-0171B	A	0.24 g	MB2978	0.36 g KOH (90%)	mill (5 min)	N2	3 °C/min	800 °C	1 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.13 g
		ground biochar (brown powder) compacted to pellet										
KJo-0172A	B	0.50 g	MB2978	0.50 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	1 h	11 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.24 g
		ground biochar (brown powder) compacted to pellet										
KJo-0172B	A	0.50 g	MB2978	0.50 g KOH (90%)	mill (2.5 min)	N2	3 °C/min	800 °C	2 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	0.17 g
		ground biochar (brown powder) compacted to pellet										
KJo-0175	A	1.60 g	MB2978	2.40 g KOH (90%)	mill (5 min)	N2	3 °C/min	800 °C	1 h	61 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	
		ground biochar (brown powder) compacted to two pellets of equal size, quartz tube shattered										
KJo-0176	B	0.24 g	MB2978	0.36 g KOH (90%)	mill (5 min)	N2	1.5 °C/min	800 °C	1 h	10 g 10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	
		ground biochar (brown powder) compacted to pellet										
KJo-0177	A	1.60 g	MB2978	2.40 g KOH (90%)	mill (5 min)	N2	3 °C/min	800 °C	1 h	10% HCl (+ water)	100 °C N2 stream (atm. Pressure)	
		ground biochar (brown powder) compacted to two pellets of equal size										